


PLUGS AND CAPS

L NPTF MALE NPTF MALE PLUG

- SAE J531



| Part Number | T1 | H1 (mm) | L1 (mm) | PN (bar) |
|-------------|--------------|---------|---------|----------|
| L-02 | 1/8-27 | 12 | 15 | 345 |
| L-04 | 1/4-18 | 14 | 19 | 275 |
| L-06 | 3/8-18 | 19 | 20 | 210 |
| L-08 | 1/2-14 | 22 | 25 | 210 |
| L-12 | 3/4-14 | 27 | 27 | 170 |
| L-16 | 1-11.1/2 | 36 | 32 | 140 |
| L-20 | 1.1/4-11.1/2 | 46 | 37 | 80 |
| L-24 | 1.1/2-11.1/2 | 50 | 40 | 70 |
| L-32 | 2-11.1/2 | 65 | 45 | 70 |